

Vehicle Model **Model Year** Part No.

Sonata - SE / ECO / Ltd. / Sport 2015 ~

C2F05 AC000

Accessory Difficulty

PEDAL KIT (A/T)

(B)

Denotes safety equipment required to be used such as a mask, safety glasses, gloves,

- Accessory Installation

Note: Difficulty stated above reflects the minimum level of expertise required to install the accessory.

(A) Customer

(B) Dealer Technician

(C) Master Technician

### **Instructional Symbols / Definitions**



Denotes warnings that may lead to serious physical injury or vehicle



Denotes quality processes to be checked prior to moving to the next



and hearing protection.



Denotes cautions to be taken to avoid physical injury or electronic component damage.



Denotes specific tools that are necessary to complete the step.







Denotes cautions to be taken to avoid vehicle and component damage



Denotes instructional steps necessary to complete the process



**Basic Required Hand Tools** 



Ratchet



10mm Socket



**Torque Wrench** 







**FMVSS 110** Compliance Information


Part Number: C2F05 AC000


1.063 lbs 0.483 kg (Gross Weight)


All dealers must determine if the weight they have added in the form of all options or accessories, when added to the weight of all Port/Dealer Installed options or accessories, exceeds the lesser of 1.5% of GVWR or 100 lbs. If the additional weight does exceed the lesser of the indicated thresholds, a "Load Carrying Capacity Reduced" label must be installed. A black, fine-point, indelible marker must be used to write by hand onto the label, the reduced carrying capacity in kilograms or pounds, which is the total weight of all added options and accessories.
Load Label Part Number: NP070 - 09003

#### Notes to the Installer:

- 1) Read the entire installation instructions prior to beginning the installation of this accessory.
- 2) Make sure the vehicle is completely clean before the accessory is installed.
- 3) Ensure the vehicle is properly protected in the area(s) that the accessory is to be installed.
- 4) To prevent vehicle damage, never place tools on top of painted surfaces, seats, dash pad, console or floor carpet/mats.
- 5) Always wear appropriate safety gear to include gloves and safety glasses when required.







Sonata Pedal Kit (A/T)

O4/25/2014

Page 4 of 5

damage to the vehicle may occur.

# HYUNDAI Genuine Accessories Function Check

	Items To Be Checked	Results Of The Check
<b>✓</b>	Verify the Accelerator Pedal Bolts are torqued to: 9.8~14.7 N.m (1.0~1.5 Kgf.m, 7.2~10.8 lb-ft). Make sure the Electrical Connector is fully seated and connected to the Accelerator Pedal.	The Accelerator Pedal is properly installed.
<b>✓</b>	Verify the Brake Pedal Pad is fully installed and not loose.	The Brake Pedal Pad is properly installed.
<b>✓</b>	Make sure the Floor Mat is installed and does not interfere with the Accellerator Pedal or Brake Pedal.	The Floor Mat is properly installed.
<b>✓</b>	Test drive the vehicle to verify function of the Accelerator Pedal.	Accelerator Pedal does not bind and operates smoothly.