

Genuine Accessories



Vehicle Model: **Tucson**

Model Year 2019-
 Part No. D3F28 AU000 (DIO)
D3F28 AU600 (PIO)
 Language English
 Rev. Date 8/14/2018

Accessory: **Applique, Rear Bumper**

Difficulty: (B)

Note: Difficulty stated above reflects the minimum level of expertise required to install the accessory:

- (A) Customer
- (B) Dealer Technician
- (C) Master Technician or Specialist

Instructional Symbols / Definitions

	Denotes warnings that may lead to serious physical injury or vehicle damage		Denotes quality processes to be checked prior to moving to the next step	Denotes personal protective equipment (PPEs) that may be required for a step. Examples of safety equipment icons noted below:	
	Denotes cautions to be taken to avoid physical injury or electronic component damage		Denotes specific tools that are necessary to complete a step		
	Denotes cautions to be taken to avoid vehicle and component damage	N O T E	Denotes important information to be reviewed during the step		
				Glasses	Gloves
				Mask	Hearing Protection

Basic Required Tools

50/50 Isopropyl Alcohol (70%) and Water (Cleaning Solution)	Shampoo and Water (Slip Mixture)	Microfiber Cloth	Nylon Squeegee with Sleeve

Part Weight (Gross)

0.06	lbs
0.03	kg

FMVSS 110 Compliance Information

All dealers must determine if the Net weight they have added in the form of all options or accessories, when added to the weight of all Port/Dealer Installed options or accessories, exceeds the lesser of 1.5% of GVWR or 100 lbs. If the additional weight does exceed the lesser of the indicated thresholds, a "Load Carrying Capacity Reduced" label must be installed. A black, fine-point, indelible marker must be used to write by hand onto the label, the reduced carrying capacity in kilograms or pounds, which is the total weight of all added options and accessories.

Load Label Part Number: **NP070 - 09003**

Notes to the installer:

- 1) Read the entire Installation Instructions prior to beginning the installation of this accessory.
- 2) Make sure the vehicle is completely clean and dry in the area(s) the part is to be installed.
- 3) Ensure the vehicle is properly protected in the area(s) that the accessory is to be installed.
- 4) NEVER place tools on painted surfaces, seating surfaces, dash pad, console or floor carpet/mats.
- 5) Always wear appropriate personal protective equipment, including gloves, safety glasses, etc., when required.
- 6) Roll down the driver's window and adjust the power seats (if applicable) prior to disconnecting battery power, if needed.
- 7) After installation, do not wash vehicle for 24 hours.


Special Instructions

Preparation - Before installation:

- 1) **Water and Shampoo:** Mix 26oz of distilled water and 1.5 ml of baby shampoo in a trigger type spray bottle marked "Slip". Note: This solution has been formulated for use where ambient and vehicle surface temperature are within a range of 65°F to 90°F. If temperatures are outside of this range, make incremental adjustments to the solution as necessary.
- 2) This product should be installed with proper installation tools.
- 3) Install this product while observing all warnings and precautions stated in the instruction booklet.
- 4) **VERY IMPORTANT:** Thoroughly wash vehicle with soap and water where accessory will be applied. If paint contaminants are found, refer to Hyundai Technical Service Bulletin 99-99-001 to determine the correct repair procedure.
- 5) **VERY IMPORTANT:** Sleeve must be installed on plastic/nylon Squeegee throughout the entire installation process.
- 6) It is recommended that the ambient temperature of the accessory and the vehicle be between 65°F and 90°F at the time of installation and for 2 hours after.
- 7) Parts storage should be flat at room temperature and in a clean dry place. **Care should be taken to avoid a dusty environment.**
- 8) Place a large towel or pad on the ground to catch wetting mixture.
- 9) Make sure you have a clean, flat table/work area to use.

Genuine Accessories

Kit Overview



No.	Qty	Description
1	1	Rear Bumper Applique
2	1	Squeegee with Sleeve

Note: Item 2 is not included in the PIO kit.

Genuine Accessories




1		50/50 Mixture of Isopropyl Alcohol (70%) & Water (Cleaning Mixture) and a Microfiber Cloth
N O T E	<p>A. Thoroughly clean the rear bumper area using 50/50 mixture of Isopropyl Alcohol (70%) & Water (Cleaning Mixture) and a Microfiber Cloth.</p> <p>B. Inspect the paint for any paint conditions that would be visible through the Rear Bumper Applique (when viewed at arm's length). Repair if necessary before proceeding.</p>	
CAUTION: Make sure bumper is completely clean and dried. Inspect bumper surface for contaminants. If paint contaminants are found, refer to Hyundai Technical Service Bulletin 99-99-001		





2		
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> Align Front Premask Here </div> <div style="text-align: center;"> </div> </div> 		
N O T E	<p>A. Dry fit Rear Bumper Applique to become familiar with the fit.</p> <p>B. Position the Rear Bumper Applique onto the bumper by visually aligning the center notch to hatch striker and the edges of the premask to the bumper features as shown.</p>	
Pay special attention to alignment		




3		Shampoo and Water (Slip Mixture)
N O T E	<p>A. Hold the Rear Bumper Applique with the liner toward you.</p> <p>B. Grasp only the handling tabs and remove the liner from the Rear Bumper Applique by rolling it downward 180° against itself.</p> <p>C. Discard the liner.</p> <p>D. Lightly and evenly mist the exposed adhesive and the area of installation on the rear bumper with the Slip Mixture.</p>	
Pay special attention to not get any fingerprints or dirt on the Rear Bumper Applique.		




4		Shampoo and Water (Slip Mixture) and Squeegee with Sleeve
<div style="display: flex; justify-content: center; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center; margin-right: 20px;"> Squeegee Sequence: </div> <div style="text-align: center;"> </div> </div>		
N O T E	<p>A. With the installation area still wet with the Slip Mixture, lay the Rear Bumper Applique back into position.</p> <p>B. Spray premask surface with the Slip Mixture to aid in a smooth squeegee stroke.</p> <p>C. Starting with the center, squeegee the top surface of the bumper using firm, overlapping squeegee strokes.</p>	
Inspect for bubbles. If bubbles are found, follow procedure in the Visual Check to remove the bubbles.		

Genuine Accessories

5		Slip Mixture and Squeegee with Sleeve
		
N O T E	<p>A. Continue to squeegee the large radius edge of the bumper from the center, working outwards as shown above.</p> <p>B. Next, squeegee the vertical face of the bumper from the center, working outwards as shown above.</p>	
	Inspect for bubbles. If bubbles are found, follow procedure in the Visual Check to remove the bubbles.	






6		
		
N O T E	A. Carefully remove the premask at 180° from the Rear Bumper Applique as shown above.	
	Do not pull premask straight up, this could lift Rear Bumper Applique.	
	Inspect for bubbles. If bubbles are found, follow procedure in the Visual Check to remove the bubbles.	

7		50/50 Mix of Isopropyl Alcohol (70%) & Water (Cleaning Mixture), Squeegee with Sleeve and Microfiber Cloth.
		
N O T E	<p>A. Complete the squeegee process; using the Alcohol & Water (Cleaning Mixture), spray the top of the Rear Bumper Applique and any lifted surfaces. Squeegee the entire Bumper Applique and any edges that may have lifted.</p> <p>B. Using Microfiber Cloth, wipe the Rear Bumper Applique and surrounding area dry, then inspect for bubbles or lifting.</p>	
	Inspect for bubbles. If bubbles are found, follow procedure in the Visual Check to remove the bubbles.	

A		
<h2>Inspection Procedure</h2> 		
N O T E	<p>Inspect for proper fit, bubbles and debris trapped underneath the Rear Bumper Applique from more than an arm's length.</p> <p>NOTE: Experienced installers may attempt to locally lift up the Rear Bumper Applique and reinstall.</p> <p>* Appropriate tools used for Applique removals are available to customers from specialty retailers.</p>	
	Hands or any tools used to lift the Rear Bumper Applique, must be saturated with SLIP Mixture. Dry hands or tools may mar the applique.	

Genuine Accessories

Visual Check

Item to be Checked		Result	
	Use only the handling tabs when handling the Rear Bumper Applique. Pay special attention to not get any fingerprints or dirt on the Rear Bumper Applique.	No dirt or fingerprints on Rear Bumper Applique.	
	Check for bubbles. If bubbles are found, re-wet Bumper Applique with SLIP Mixture and using a Squeegee with Sleeve, push/pull/remove bubbles to the closest edge of the Rear Bumper Applique.	No bubbles present.	
	Make sure Rear Bumper Applique is fully adhered.	Rear Bumper Applique is not lifting and is fully adhered. Take special care to make sure all edges are fully adhered.	
	Make sure Rear Bumper Applique is free of any remaining premask adhesive after installation. Clean the Bumper Applique with soap and water if necessary.	No premask adhesive remaining on Rear Bumper Applique.	
	If an installation error occurs, i.e. scratched / marred film, dirt / debris under Bumper Applique, crooked installation, etc., installer should remove, discard and replace the Rear Bumper Applique.	Rear Bumper Applique is installed correctly.	