


Notes to the installer:


- 1 Read the entire Installation Instructions prior to beginning the installation of the part.
- 2 Make sure the vehicle is completely clean and dry in the area(s) the part is to be installed.
- 3 Ensure the vehicle is properly protected in the area(s) that the accessory is to be installed.
- 4 NEVER place tools on painted surfaces, seating surfaces, dash pad, console or floor carpet/mats.
- 5 Always wear appropriate personal protective equipment, including gloves, safety glasses, etc., when required.


Load Label Part Number: NP070 - 09003



Zip Lock Bag Important Notice Card

1 1





Visual Check

Item to be Checked



Make sure each Wheel Lock is torqued to the factory specification.

Make sure the Wheel Lock Key and vehicle lug nuts are properly stored in the clamshell package.

Ensure clamshell package is securely placed to avoid any rattles/noise.

Result	
Wheel Locks torqued to factory specifications.	
Wheel Lock Key and vehicle lug nuts properly stored.	
Clamshell is securely placed in vehicle.	