

# Genuine Accessories



Vehicle Model: **Elantra**

Model Year 2019~  
 Part No. F3F40 AU100  
 Language English  
 Rev. Date 6/5/2018

Accessory: **Spare Tire Kit**

Difficulty: ( B )

**Note:** Difficulty stated above reflects the minimum level of expertise required to install the accessory:  
 (A) Customer  
 (B) Dealer Technician  
 (C) Master Technician or Specialist

### Instructional Symbols / Definitions

	Denotes warnings that may lead to serious physical injury or vehicle damage		Denotes quality processes to be checked prior to moving to the next step	Denotes personal protective equipment (PPEs) that may be required for a step. Examples of safety equipment icons noted below:	
	Denotes cautions to be taken to avoid physical injury or electronic component damage		Denotes specific tools that are necessary to complete a step		
	Denotes cautions to be taken to avoid vehicle and component damage	<b>N O T E</b>	Denotes important information to be reviewed during the step		

### Basic Required Tools

Clean Cloth	50/50 Isopropyl (70%) and Water Mix

### Specialty Required Tools

Tire Mounting Machine	Valve Stem Tool

### Part Weight (Gross)

<b>19.3</b>	lbs
<b>8.75</b>	kg

### FMVSS 110 Compliance Information

All dealers must determine if the Net weight they have added in the form of all options or accessories, when added to the weight of all Port/Dealer Installed options or accessories, exceeds the lesser of 1.5% of GVWR or 100 lbs. If the additional weight does exceed the lesser of the indicated thresholds, a "Load Carrying Capacity Reduced" label must be installed. A black, fine-point, indelible marker must be used to write by hand onto the label, the reduced carrying capacity in kilograms or pounds, which is the total weight of all added options and accessories.  
**Load Label Part Number: NP070-09003**

### Record Tire Weight

lbs/kg


### Add for Total Spare Tire Kit Weight

lbs/kg

### Notes to the installer:


- 1) Read the entire Installation Instructions prior to beginning the installation of the part.
- 2) Make sure the vehicle is completely clean and dry in the area(s) the part is to be installed.
- 3) Ensure the vehicle is properly protected in the area(s) that the accessory is to be installed.
- 4) NEVER place tools on painted surfaces, seating surfaces, dash pad, console or floor carpet/mats.
- 5) Always wear appropriate personal protective equipment, including gloves, safety glasses, etc., when required.
- 6) Inflate Spare Tire to 60 PSI.
- 7) When calculating the total weight of the Spare Tire Kit, be sure to include the weight of the Temporary Spare Tire being installed.


### Kit Overview





No.	Qty	Description	No.	Qty	Description
1	1	Steel Wheel	6	1	Lug Nut Wrench
2	1	Foam Tool Case	7	1	Screwdriver
3	1	Jack	8	4	Tire Pressure Label
4	1	Hold-Down Clamp	9	1	Valve-Tire
5	1	Bar			

## Genuine Accessories




1		Valve Stem Tool and Tire Mounting Machine
		
N O T E	<p>A. Open the Spare Tire Kit and install the Valve Stem onto the Wheel Assembly.</p> <p>B. Install a T125/80D15 Temporary Spare Tire sourced through the Hyundai Authorized Tire Program, onto the Wheel Assembly. Inflate to 60 PSI.</p>	




2		
		
N O T E	<p>A. Open the Trunk Lid remove the Trunk Floor Board.</p>	




3		Clean Cloth and 50/50 Isopropyl (70%) and Water Mix
		
N O T E	<p>A. Remove the factory equipped Tire Mobility Kit and Foam Organizer from the spare tire well.</p> <p>B. If necessary, using a Clean Cloth and 50/50 Isopropyl (70%) and Water Mix, thoroughly clean the spare tire well area.</p>	
	<p>Dealer must directly hand the vehicle's Tire Mobility Kit and Foam Organizer to the vehicle owner. Do not leave the Tire Mobility Kit and Foam Organizer in the trunk.</p>	




4		
 <div style="position: absolute; top: 50%; left: 50%; transform: translate(-50%, -50%); border: 1px solid black; padding: 5px;"> <p style="margin: 0;">"Valve Stem Down"</p> </div>		
N O T E	<p>A. Insert the Spare Tire Assembly into the spare tire well with the Valve Stem facing down.</p>	

## Genuine Accessories

5		
		
N O T E	<p>A. Secure the Spare Tire Assembly to the spare tire well by installing the supplied Hold-Down Clamp and turn clockwise until tightened.</p>	
	<p>Hand tighten Hold-Down Clamp until firm and Spare Tire Assembly is secured.</p>	




6		
		
N O T E	<p>A. Place the supplied Foam Tool Case on top of the Spare Tire Assembly. B. Install the supplied Jack, Bar, Lug Nut Wrench, and Screwdriver into the Foam Tool Case.</p>	
	<p>Make sure all tools are firmly in place to prevent any rattles.</p>	

7		
		
N O T E	<p>A. Reinstall the Trunk Floor Board.</p>	
		

8		Clean Cloth and 50/50 Isopropyl (70%) and Water Mix
		
N O T E	<p>A. Remove the factory installed tire pressure label located on the inside of the driver's side door opening B-Pillar. Clean off any remaining adhesive using a Clean Cloth and 50/50 Isopropyl (70%) and Water Mix, and allow to dry thoroughly. B. As shown above, install one of the new Tire Pressure Labels by comparing the tire size on the label being replaced with one of the new labels provided. The new label includes spare tire pressure information. C. Discard the other three (3) labels.</p>	
	<p>Make sure to use the correct warning label for the tire size installed on vehicle.</p>	

## Genuine Accessories

### Visual Check

Item to be Checked		Result	
	Hand tighten hold-down clamp until firm and secure.	Hold-down clamp is tight.	
	Make sure all tools are firmly in place to prevent any rattles.	Tools are not loose.	
	Make sure to use the correct tire pressure label to match the factory tire size on the vehicle.	Correct tire pressure label installed, matching the factory tire size on the vehicle.	